User Instructions for Toshiba CIX



C.I.D. = 10 most recent calls to your phone

D.N.D. = Do Not Disturb (when lit, no calls can reach you)

MAKING AN OUTSIDE CALL: Lift handset, dial 9 plus a phone number

ANSWER CALLS RINGING AT YOUR EXTENSION: Lift handset or press SPKR

PICKUP A CALL RINGING AT ANOTHER PHONE: Dial #5#5 _____ (extension number)

TRANSFERING A CALL: Press CNF/TRN and dial extension, hang up

If you have a button for that station, simply press the button then hang up

TRANSFER CALL TO MAILBOX: Press **VM TRANS,** dial extension, press **#**, hang up

If you have a button for that station, press VM TRANS, press the button, hang up

PARK (system hold) and PICKUP:

To park call: Press the **PARK** button, press * and watch display for a Zone number **(7000-7019)**

To pickup parked call: Press the **PARK** button, dial Zone number **(7000-7019)**

PAGING: Lift handset, press a PAGE button, make announcement

CONFERENCE CALL: Press **CNF/TRN**, dial number for second party,

when answered press CNF/TRN again

VOLUME CONTROLS: Press and hold the Volume ▲ or ▼ during the function

Programming Blank Buttons

TO MAKE EXTENSION BUTTONS (DSS buttons):

Enter User Programming Mode by dialing #9876

Press **HOLD**

Press the button you want to program

Dial feature code $\bf 610$ plus the extension number you want it to be

Then press the **same button (flashing)** again to store data

PERSONAL SPEED DIAL NUMBERS AND ONE-TOUCH BUTTONS:

Dial **#9876**, press **Spdial**, then dial a bin number 100-109. Enter the 9 + the number you want programmed and store the data by pressing **Spdial** again. (*System-wide* speed dial bins are 200-799)

To use Speed Dial entries: Lift handset, press **Spdial** and dial a speed dial bin.

To create a one-touch Speed Dial button, dial **#9876**, choose a **one touch button**, dial 9 + phone number, then press the **same button (flashing)** again to store data.